



Instructions for Hood opening with broken Cable

Looking into the Windshield Wiper area, locate the two Plugs covering the Hood Lock Access Holes and remove the plugs by pushing or pulling on the plugs depending on the direction which they were last installed. Using a Flat Blade screwdriver go through the Access Hole and manipulate the latch until it releases. Usually by pushing the Lock Lever forward, or to the side, releases the latches.